




23<sup>rd</sup> DECEMBER 1994

REF.




ABONNEMENT GME

# DK5 ENGINE

## ● CYLINDERHEAD

MAN 058931



GB



**AUTOMOBILES CITROËN**  
DIRECTION COMMERCE EUROPE  
DOCUMENTATION APRÈS VENTE

### **CYLINDERHEAD**

CYLINDER HEAD TIGHTENING .....	3
REMOVING – REFITTING THE CYLINDER HEAD (IN THE VEHICLE) .....	5
REMOVING – REFITTING THE CAMSHAFT .....	11

## CYLINDER HEAD TIGHTENING

### 1 – RECOMMENDED TOOLS




Fig : B1DP001C

[1] adaptor for angular tightening.

[1]	4069-T
-----	--------

### 2 – CHECKING CYLINDER HEAD BOLTS BEFORE RE-USE

**IMPERATIVE** : It is necessary to check the length of the cylinderhead bolts before re-using them.




Fig : B1DP00QC

X overall length of the screw.

Engine code	screw Ø	X
DK5	10x150	162.5 mm
	12x150	153.5 mm

**IMPERATIVE** : Use new screws if their lengths exceed (X).

## 3 – PRIOR CONDITIONS

Clean the joint faces.

(do not use a sharp or abrasive tool).

Check the flatness of the cylinderhead (0,03 mm).

Clean out the threads of the cylinder block head screws with a tap (10x150 and 12x150 taps).

The cylinderhead gasket will be fitted dry.




Fig : B1DP00RC

Smear the threads and contact faces under heads of the bolts with MOLYKOTE G. RAPID PLUS grease.

## 4 – CYLINDER HEAD TIGHTENING

**IMPERATIVE :** Tighten the cylinderhead bolts in the order indicated.

### 4.1 – Generality

This tightening method avoids the need to warm up the engine before the final tightening of the cylinderhead.

No retightening of the cylinderhead is required at the first service.

### 4.2 – Tightening sequence




Fig : B1BP03XC

This operation is performed in 2 stages.

First stage :

- proceed bolt by bolt in the order shown (1 to 14)
- tightening of screws 12x150 to 5 mda.N
- proceed bolt by bolt in the order shown (15 to 22)
- tightening of screws 10x150 to 3.5 mda.N

Second stage :

- proceed bolt by bolt in the order shown (1 to 22)
- angular tightening of  $120^\circ \pm 5^\circ$  utilising tool [1]

## REMOVING – REFITTING THE CYLINDER HEAD (IN THE VEHICLE)

### 1 – RECOMMENDED TOOLS




Fig : E5-P059C

[1] hose clamp (9029-T).

Additional tools :

- setting rod 5711-TQ (tool box 5711-T)
- spanner 5711-TR (tool box 5711-T)
- tensioning spanner 5711-TS (tool box 5711-T)
- flywheel setting rod 7014-TJ (tool box 7004-T)
- camshaft gear wheel setting rod 5711-TA (tool box 5711-T)
- injection pump setting rod 5711-TB (tool box 5711-T)
- belt tension measuring instrument 4099-T - 4122-T
- LHM reservoir/filter assembly cover 9004-T
- filling cylinder 4520-T
- set of levers to free cylinderhead 149-T (tool box 4067-T)

### 2 – REMOVAL

Raise and support the vehicle, with the wheels hanging free.

Unclip the battery trim cover :

- 2 attachment points, front side end
- 1 attachment point marked by an arrow towards the air filter (using a screwdriver)

Remove :

- the battery
- the protective plate under the engine
- the RH front road wheel
- the engine protection plate situated under the R.H. front wheelarch
- the R.H. front mud shield

Drain :

- the gearbox
- the cooling system (see the relevant operation)

Remove :

- the R.H. drive shaft (see the relevant operation)
- the turbocharger (see the relevant operation)




Fig : B1DP02GC

Remove :

- air filter (1) (together with its sleeve)
- the LHM fluid reservoir (2)

Fit the LHM reservoir/filter assembly cover.

Take out the fixing screws then push aside :

- fuse box (3)
- pre-heater control unit (5)
- diesel fuel priming pump (6)
- dehydrator reservoir (7)
- the battery tray

## CYLINDERHEAD

Unclip :

- the electrical harnesses from the battery tray
- fuse carrier boxes (4) from the cooling fans unit

Uncouple the bonnet opening cable.

Remove :

- the battery tray
- trim cover (6)
- the water pump drive belt (see the relevant operation)




Fig : B1DP02HC

Remove sleeve (9).

Disconnect :

- the Diesel fuel inlet and return pipes (10) from the heater
- flexible hoses (11), utilising tool [1]
- connectors (12)




Fig : B1DP02IC

Take off clamping collar (13).

Disconnect the connection hose from the header tank, utilising tool [1].

Remove header tank (14).

Separate the wiring harnesses from the harness support (15).

Remove :

- wiring harness support (15)
- injector pipes

Disconnect :

- the injector return pipe
- the 2 heater plug feed pipes
- number 3 cylinder injector connector




Fig : B1DP02JC

Withdraw the E.C.U.s from E.C.U. tray (16).

Remove E.C.U. tray (16).




Fig : B1DP02KC

Remove :

- connector (17) trim cover
- connector (17) fixing screws

- sleeve (18) (rotate by 1/4 turn)
- Unclip the electrical harnesses.  
Remove the accessory drive belt (see the relevant operation).




Fig : B1DP02LC

Remove :

- roller (19)
- upper timing cover (20)
- the timing belt (see the relevant operation)




Fig : B1DP02MC

Remove camshaft gear wheel (21) (together with its fixing plate).




Fig : B1DP02NC

Remove :

- screws (22)
- roller tensioner (23)




Fig : B1DP02PC

Remove electrovalve (24).

Unclip connecting hoses (25).

## CYLINDERHEAD




Fig : B1DP02QC

Disconnect metal sleeve (26).




Fig : B1DP02SC

Remove :

- flexible retainer (30)
- the cylinder head bolts (22 screws)
- the cylinder head




Fig : B1DP02RC

Remove :

- air reservoir (27) (together with its supports)
- the cylinder head cover (28)
- closing plate (29)



## 3 – REFITTING

### 3.1 – Generality

Clean the joint faces (do not use a sharp or abrasive tool).

Check the flatness of the cylinderhead : maximum permissible bow = 0.03 mm.

Clean out the threads of the cylinder block head screws with a tap (10x150 and 12x150 taps).

Blow compressed air in the various threads of the cylinder block.

**IMPERATIVE** : It is necessary to check the length of the cylinderhead bolts before re-using them.

Use new screws if their lengths exceed :

- 162.5 mm (screw Ø10)
- 153.5 mm (screw Ø12)

Brush the threads of the cylinder head bolts.

Reinstall the cylinderhead screws with the threads and under heads previously coated with grease MOLYKOTE G RAPID.

### 3.2 – Cylinder head




Fig : B1DP02TC

Check if dowels (31) are fitted.

Position :

- the cylinderhead gasket
- the cylinder head
- the cylinder head bolts

### 3.2.1 – Cylinder head tightening




Fig : B1BP03XC

#### 3.2.2 – First stage

Proceed bolt by bolt in the order shown (1 to 14).

Tightening torque of bolts (Ø12) : 5 m.daN.

Proceed bolt by bolt in the order shown (15 to 22).

Tightening torque of bolts (Ø10) : 3.5 m.daN.

#### 3.2.3 – Second stage

Proceed bolt by bolt in the order shown (1 to 22).

Angular tightening of 120° ; tolerance : ± 5°.

**NOTE** : It is not necessary to retighten the cylinderhead after the engine warming up.

#### 3.2.4 – Refitting (continued)

Fit :

- flexible retainer (30) ; tightening torque = 5 m.daN
- closing plate (29) ; tightening torque = 1.5 m.daN
- the cylinder head cover (28) ; tightening torque = 0.8 m.daN
- air reservoir (27) ; tightening torque = 0.8 m.daN

Reconnect metal sleeve (26).

Clip connecting hoses (25) in place.

Relocate :

- electrovalve (24)
- roller tensioner (23)
- screws (22)
- the camshaft gear wheel (together with its fixing plate) ; tightening torque = 4.3 m.daN
- the timing belt (see the relevant operation)




Fig : B1DP02LC

**Refit :**

- upper timing cover (20)
- roller (19)
- the auxiliary equipment drive belt (see the relevant operation)

Clip the electrical harnesses back.

**Reinstall :**

- sleeve (18) (rotate by 1/4 turn)
- connector (17)
- connector (17) trim cover
- E.C.U. tray (16)
- the E.C.U.s

**Reconnect :**

- the 2 heater plug feed pipes
- number 3 cylinder injector connector
- the injector return pipe

**Relocate :**

- injector pipes
- wiring harness support (15)
- clip the electrical harnesses to the harness support (15)

Reconnect the connecting hose to the header tank, utilising tool [1].

**Fit :**

- header tank (14)
- clamping collar (13)




Fig : B1DP02HC

**Reconnect :**

- flexible hoses (11) ; use tools [1]
- connectors (12)
- the Diesel fuel inlet and return pipes (10) from the heater

**Refit :**

- sleeve (9)
- the water pump drive belt (see the relevant operation)
- trim cover (8)
- the battery tray

Couple up the bonnet release cable.

**Clip in place :**

- the wiring harnesses to the battery tray
- fuse box (4)

**Relocate :**

- the dehydrator reservoir
- diesel fuel priming pump (6)
- pre-heater control unit (5)
- fuse box (3)
- the LHM fluid reservoir (2)
- air filter (1) (together with its sleeve)
- the turbocharger (see the relevant operation)
- the R.H. drive shaft (see the relevant operation)

Refill the gearbox with oil and top up to level.

**Reinstall :**

- the R.H. front mud shield
- the engine protection plate situated under the R.H. front wheelarch
- the RH front road wheel
- the protective plate under the engine
- the battery

Clip in place the battery trim cover.

Return the vehicle to its wheels.

Fill and bleed the cooling system (see the relevant operation).

## REMOVING – REFITTING THE CAMSHAFT

### 1 – RECOMMENDED TOOLS




Fig : E5-P05XC

[1] camshaft gear wheel setting rod 5711-TA  
(tool box 5711-T).




Fig : E5-P05ZC

[3] seal fitting drift - camshaft 5711-TF  
(tool box 5711-T).




Fig : E5-P05YC

[2] LHM reservoir/filter assembly cover 9004-T.

Additional tools :

- setting rod 5711-TQ (tool box 5711-T)
- spanner 5711-TR (tool box 5711-T)
- tensioning spanner 5711-TS (tool box 5711-T)
- flywheel setting rod 7014-TJ (tool box 7004-T)
- injection pump setting rod 5711-TB  
(tool box 5711-T)
- belt tension measuring instrument : 4099-T or  
4122-T

## 2 – REMOVAL

Lift and support the vehicle with the front wheels suspended.

Unclip the battery trim cover :

- 2 attachment points, front side end
- 1 attachment point marked by an arrow towards the air filter (using a screwdriver)

Remove :

- the battery
- the protective plate under the engine
- the RH front road wheel
- the engine protection plate situated under the R.H. front wheelarch
- the R.H. front mud shield

Drain the cooling system (see the relevant operation).




Fig : B1DP02GC

Remove :

- air filter (1) (together with its sleeve)
- the LHM fluid reservoir (2)

Locate the LHM reservoir/filter assembly cover [2].

Take out the fixing screws then push aside :

- fuse box (3)
- pre-heater control unit (5)
- diesel fuel priming pump (6)
- the dehydrator reservoir (7)
- the battery tray

Unclip :

- the electrical harnesses from the battery tray
- fuse carrier boxes (4) from the cooling fans unit

Uncouple the bonnet opening cable.

Remove :

- trim cover (8)
- the water pump drive belt (see the relevant operation)
- the camshaft pulley




Fig : B1DP02VC

Withdraw the E.C.U.s from E.C.U. tray (9).

Remove E.C.U. tray (9).




Fig : B1DP02WC

Remove :

- connector (10) trim cover
- connector (10) fixing screws
- sleeve (11) (rotate by 1/4 turn)

Unclip the electrical harnesses.

Remove the accessory drive belt (see the relevant operation).




Fig : B1DP02XC

Remove :

- roller (12)
- upper timing cover (13)
- the timing belt : carry out a partial removal operation (see the relevant operation)




Fig : B1DP02ZC

Remove :

- camshaft plate (15)
- screw (16)




Fig : B1DP02YC

Take off clamping collar (14).




Fig : B1DP030C

Remove :

- electrovalve (17)
- air reservoir (18) (together with its supports)
- mounting bracket (19)

## CYLINDERHEAD




Fig : B1DP031C

Remove :

- the cylinder head cover (20)
- closing plate (21)




Fig : B1DP032C

Remove :

- screws (22)
- camshaft carrier bearing (23)




Fig : B1DP033D

Remove :

- lipped seals (24)
- flange (25)
- camshaft (26)

## 3 – REFITTING

Clean the joint faces.

Do not use abrasives or sharp tools on the joint faces.

Check the condition of the hydraulic push-rods.




Fig : B1DP034D

Lubricate the camshaft with new engine oil.

Refit :

- camshaft (26) into camshaft carrier bearing (23)
- flange (25) ; tighten to 1,15 m.daN  
use new screws (pre-coated).

Oil the new lipped seals (24).

Put lipped seal [24] into place with tool (3).

Position :

- washer (27)
- nut (28)

Tighten nut (28) and stop when lipped seal (24) is located.

Remove :

- nut (28)
- washer (27)
- tool [3]

## CYLINDERHEAD




Fig : B1DP035C

Refit the camshaft plate (15).

Peg the camshaft with setting rod [1].

**IMPERATIVE :** Do not rotate camshaft (26) as the valves may be damaged when fitting the camshaft bearing to the cylinderhead.

Remove :

- tool [1]
- camshaft plate (15)




Fig : B1DP01JC

Smear the upper contact face of the cylinderhead with sealing product (E10).

Relocate :

- camshaft carrier bearing (23) (to the cylinderhead)
- screws (22) ; tighten to 2 m.daN, observing the correct tightening order : 1-14
- closing plate (21) ; tighten to 1.5 m.daN
- the cylinder head cover (20) ; tighten to 0.8 m.daN
- air reservoir (18) (together with its supports) (see operation : removing-refitting the EGR valve)
- electrovalve (17)
- mounting bracket (19)
- screw (16)
- camshaft plate (15) (new nut) ; tighten to 4.3 m.daN
- the timing belt : refit partly (see the relevant operation)
- upper timing cover (13)
- roller (12)
- sleeve (11) (rotate by 1/4 turn)
- connector (10)
- connector (10) trim cover

Clip the electrical harnesses back.

Install :

- the auxiliary equipment drive belt (see the relevant operation)
- E.C.U. tray (9)
- the E.C.U.s




Fig : B1DP02GC

Fit :

- the camshaft pulley (new nut) ; tighten to 4.3 m.daN
- the water pump drive belt (see the relevant operation)
- trim cover (8)

Clip in place :

- the wiring harnesses to the battery tray
- fuse carrier boxes (4) from the cooling fans unit



Locate :

- the battery tray
- the bonnet release cable
- the dehydrator reservoir (7)
- diesel fuel priming pump (6)
- pre-heater control unit (5)
- fuse box (3)
- the LHM fluid reservoir (2)
- air filter (1)
- the R.H. front mud shield
- the engine protection plate situated under the R.H. front wheelarch
- the RH front road wheel
- the protective plate under the engine
- the battery

Clip in place the battery trim cover.

Return the vehicle to its wheels.

Fill and bleed the cooling system (see the relevant operation).